



□ □ RADIAL

The fender profile ready in three steps.
Be one step ahead.

COLD FITTING

NO NEED TO PRE-HEAT



1 Screw or rivet
the rigid track.



2 Hand bending
the track.



3 Install the soft pvc profile.
No need pre-heating.

see how to fit: www.youtube.com/tessilmare

